Rail Saw

- 26" abrasive blade cuts anywhere between the shoulders.
- Hydraulic rail clamps on saw and chassis.
- Operator stands away from blade while cutting.
- Sparks directed away from saw into containment shield.
- Cab available air conditioned and heated for 4+ passengers.
- Operator always faces direction of travel.
- 4 wheel drive.







Sperling Railway Services, Inc.

4313 Southway St. SW Canton, Ohio 44706 Phone: 330-479-2004 Fax: 330-479-2006 E-mail: info@sperlingrailway.com Website: www.sperlingrailway.com